

K&H Manufacturing, Inc.
Thermo Kitty Sill

Thank you for purchasing K&H Manufacturing's THERMO KITTYSILL. When used correctly, your Thermo Kitty sill should provide years of hassle free warmth for your pet. Your THERMO KITTYSILL is intended for indoor use. **Its unique heating system is designed to become warm, not hot.**

WARNING: This is an electrical product. Read all directions and precautions carefully before operating. Failure to properly follow all directions and instructions may lead to electric shock or fire, which could cause serious bodily injury.

For household use Only
Important safeguards

When using electrical appliances, basic safety precautions should always be followed including the following:

1. **Read all instructions.**
2. To protect against electrical hazards, **DO NOT** immerse cord, plug or appliance in water or other liquid.
3. **Close supervision is necessary** when used by or near children.
4. **ALWAYS** unplug from outlet when not in use.
5. **DO NOT** operate any electrical appliance with a damaged cord or plug, or if the appliance malfunctions or has been damaged in any manner. **RETURN** all malfunctioning appliances to the factory for examination.
6. **DO NOT** use appliance for other than its intended use.
7. **DO NOT PUNCTURE HEATER FOR ANY REASON.**
8. For use with 110-120 volt AC **ONLY**.
9. **CORD MUST EXIT** Kitty sill towards wall to keep away from normal travel of pet.
10. Pad must lie flat inside bed. **DO NOT INSTALL BENT OR FOLDED.**
11. When using this product, make sure your pet has the option of sleeping on or OFF the bed.
12. **SAVE THESE INSTRUCTIONS FOR YOUR USE.**

Instructions

1. Carefully position heating pad between foam pieces and run cord through notch in foam and out the bottom of the Kitty Sill. Place cover over foam and edge of the plastic Kitty Sill tray.
2. Remove sloth cover for washing. Machine wash cold, air dry.
3. Follow the above instructions when reassembling your THERMO KITTYSILL.

Testing your new Kitty Sill

After operating 1-2 hours, place your hands on your pet's new THERMO KITTYSILL for 20-30 seconds, applying pressure. You should begin feeling the gentle warmth wick through the plush foam Kitty Sill. For safety and enjoyment of your pet, the THERMO KITTYSILL is designed to provide mild radiant warmth. **THE KITTYSILL WILL NOT GET HOT!**

How to install your new Kitty Sill

Your new Kitty Sill can be attached to virtually any windowsill using one of two provided attachment methods.

Velcro® attachment: (For any windowsill.) Upon removing the Kitty Sill from box, note the forward edge of the tray portion. The screw holes in the tray are to be nearest the window. Hold the tray onto desired mounting position on the windowsill and determine positioning of legs. Snap legs into position and hold up to windowsill again. Be sure the Kitty Sill is level. If the Kitty Sill is not level, snap legs into another position. Once desired adjustments are made, remove tray and attach Velcro® to the raised portion on the bottom of the Kitty Sill tray directly under the two outside screw holes. Gently set the tray down onto windowsill in the desired position. Press down firmly above the Velcro® strips to ensure proper adhesion to windowsill. For best results, wait 24 hours before using. (This gives the Velcro® adhesive optimal time for proper adhesion.)

Screw attachment: (For wood windowsills.) Remove cloth cover, foam and heating unit. (If unit is a heated Kitty Sill.) Use same positioning techniques as above. Once desired position is achieved, mark windowsill through the screw holes in tray using a pencil. Using a 1/16" drill bit, drill 1" down into windowsill. Use a phillips head screwdriver to attach Kitty Sill with the 3 provided screws. Replace heating unit, (if unit is a heated Kitty Sill) foam, and cloth cover and your Kitty Sill is ready for use. Rubber bumpers may be attached to the legs where they meet the wall if more stability is needed.

Limited 1 year Warranty

K & H manufacturing warrants to the original consumer, that this product will be free of defects and workmanship for a period of one year from the date of purchase. The manufacturer's liability hereunder is limited to replacement of the product. This warranty is void if the product has been damaged by accident, unreasonable use, neglect, tampering, or other causes not arising from defects in material or workmanship.

To exercise your warranty: If during the warranty period, your product malfunctions return it to the place of purchase with your original purchase receipt. If this cannot be done, return the product, postage prepaid, to K & H Manufacturing, with dated proof of purchase or original dated receipt. A return authorization number, obtained by calling (719) 591-6950 must accompany all returns to manufacturer. Please include a note explaining the problem when returning the product.