

## **Thermo-Pond™ Instructions**

Just plug in your Thermo-Pond™ and float it in your pond dome side up. You should begin to use your Thermo-Pond™ when your pond has iced over. If the ice on your pond is more than 2 inches thick, drill a hole with an ice auger and place Thermo-Pond™ over the hole. If the ice is only 1 or 2 inches thick, place Thermo-Pond™ on the ice and it will melt its way through. Do not chop through the ice in smaller ponds as the shock waves can damage or kill your fish. Always keep safety your number one priority. Never walk on thin ice. Try to position your Thermo-Pond™ within arm's reach of shore to avoid walking on thin ice. Snow and ice should be removed from the top of your Thermo-Pond™. Thermo-Pond™ is recommended for ponds up to 1000 gallons, an additional Thermo-Pond™ should be used for each additional 1000 gallons of water. An additional Thermo-Pond™ should also be used in ponds requiring extra gas exchange due to excessive plant decay or large quantities of fish under the ice.

After the winter season, wipe down your Thermo-Pond™ with a damp cloth and store in a clean dry place. Always inspect your Thermo-Pond™ before using. If there are cracks in the cord or plastic housing, do not use. Discard immediately.

Please consult your Pond professional on tips for overwintering fish.

**Patented**

### Limited 1 year Warranty

**K & H Manufacturing** warrants to the original consumer, that this product will be free of defects and workmanship for a period of one year from the date of purchase. The manufacturer's liability hereunder is limited to replacement of the product. This warranty is void if the product has been damaged by accident, unreasonable use, neglect, tampering, or other causes not arising from defects in material or workmanship.

**To exercise your warranty:** If, during the warranty period, your product malfunctions, return it to the place of purchase with your **original purchase receipt**. If this cannot be done, return the product, postage prepaid, to K & H Manufacturing, with **dated proof of purchase or original dated receipt**. All returns to manufacturer must be accompanied by a return authorization number, obtained by calling (719) 591-6950. Please include a note explaining the problem when returning the product.